




The DAV-P-A air relief valve releases entrapped air pockets which accumulate at the high point in the filter or piping systems. Initially, water in the filter or piping raises the valve float and positively seals the specially designed small orifice. During operation, entrapped air rises into the high point of the valve displacing water and lowering the float. This opens the orifice allowing the air to escape. When the air is evacuated, the water again raises the float, resealing the orifice.



MARK	QTY	DESCRIPTION	
1	1	3/4" AIR RELIEF VALVE	
2	1	3/4" SCH. 80 PVC THREADED TEE	
3	2	3/4" SCH.80 PVC BALL VALVE	
4	1	3/4" SCH.80 PVC CLOSE NIPPLE	

**BILL OF MATERIAL FOR ONE ASSEMBLY**

ALL ITEMS ARE SHIPPED LOOSE  
FACTORY PACKAGED

